

## VI.5.3D-SYSTEM-PERMDATE PROGRAM FCST HCL TECHNIQUE PERMDATE

### Purpose

Technique PERMDATE sets the creation date of the time series to be read from the ESP Permanent Time Series files for Function ESP.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is Nonuniversal.

If one of the Arguments is zero, it and any remaining Arguments will not be checked against the creation date and time.

### Form of Input

PERMDATE month day year hourmin seconds

where month is the month  
day is the day  
year is the year (4 digits)  
hourmin is the hour and minute  
seconds are the seconds and milliseconds

### Example

PERMDATE 3 5 1982

Time series read from the ESP Permanent Time Series file must have been created March 5, 1982.